

What does the label "DY" on a Forklift stand for?

The label "DY" indicates the truck is diesel-fueled, that it meets the requirements of "DS", and that it does not have any electrical equipment installed. A DY truck makes use of air-starters and has the provision to limit the surface temperature of its components. A DY truck is similar in application to the EE electric truck.